


RH FRONT SIDE
MARKER LAMPRH FRONT TURN/
MARKER LAMPRH HEADLAMP
RETRACTOR

RH HEADLAMP




RH HORN





LH HORN



LH HEADLAMP

LH HEADLAMP
RETRACTORLH FRONT TURN/
MARKER LAMPLH FRONT SIDE
MARKER LAMPZONE F-157 OR
F-175 LEFT OF
RELAY BOX
AT LH INTERIOR
KICK PANEL

TO GROUND

ZONE F-158 OR
F-180 ABOVE
RELAY BOX AT
LH INTERIOR
KICK PANELHEADLAMP
RELAYTRANSAXLE
FLUID TEMPERATURE
SWITCH

A

B

C

D

E

F