

17

18

19

20

21

22

BATTERY

ALTERNATOR/REGULATOR

STARTER MOTOR

POWER STEERING SW.

OIL LEVEL SENSOR

OIL PRESSURE SENSOR

CAPACITOR

TO GROUND

TO 14290  
ZONE 12-A

FUEL INJECTOR #1

FUEL INJECTOR #3

FUEL INJECTOR #2

FUEL INJECTOR #4

BAC SOLENOID (GL, GT)

CANISTER PURGE SOLENOID (GL)

CANISTER PURGE SOLENOID (GT)

EGR SOLENOID VALVE (GL)

EGR SOLENOID VALVE (GT ONLY) (VENT) (AIR)

PRC SOLENOID VALVE (GL)

PRC SOLENOID VALVE (GT)

TURBO BOOST CONTROL SOLENOID VALVE (GT)

VIP TEST CONNECTOR

14290

TO 14405  
ZONE 128-F

C255

14290

TO 14405  
ZONE 128-F  
(GT ONLY)

C254

ABS HYD. ACTUATOR ASY.

ABS RELAY

2.2L : GL  
2.2L TURBO : GT--- : GT  
--- : CANADA

17

18

19

20

21

22